


Parallel Data Non-Sequential Count Troubleshooting Flow Chart



*Note: The digitizer's outputs are the "uncommitted" collectors of discrete Darlington transistors. The collectors must be pulled up to a voltage from +3 to +40Vdc through a current limiting resistor in the receiving device. Pull-up voltages and resistors vary with the manufacturer. Common examples include:
 +5Vdc/4.7KΩ
 +9Vdc/10KΩ
 +15Vdc/15KΩ